



IPC/JEDEC-9704A

JEDEC

Printed Circuit Assembly Strain Gage Test Guideline

Developed by the JEDEC Reliability Test Methods for Packaged Devices Committee (JC-14.1) and the SMT Attachment Reliability Test Methods Task Group (6-10d) of the Product Reliability Committee (6-10) of IPC

Supersedes:

IPC/JEDEC-9704 - June 2005

Users of this publication are encouraged to participate in the development of future revisions.

Contact:

IPC
3000 Lakeside Drive, Suite 309S
Bannockburn, Illinois
60015-1219
Tel 847 615.7100
Fax 847 615.7105

Table of Contents

1 SCOPE	1	4 DATA ANALYSIS AND REPORTING	15
1.1 Purpose	1	4.1 Analysis Requirements	15
1.2 Background	1	4.2 Test Frequency	16
1.3 Terms and Definitions	3	4.3 Strain Gage Test Report Template	16
1.3.1 Area Array Component	3	4.3.1 Abstract	16
1.3.2 Component	3	4.3.2 Introduction	16
1.3.3 Interconnect	3	4.3.3 Test Apparatus and Setup	16
1.3.4 Non-Area Array Component	3	4.3.4 Results	16
1.3.5 Diagonal Strain (ϵ_d)	3		
1.3.6 Microstrain	3		
1.3.7 Principal Strain (ϵ_p)	3		
1.3.8 Rosette	3		
1.3.9 Pad Cratering	3		
1.3.10 Stacked Rosette Strain Gage	3		
1.3.11 Strain	3		
1.3.12 Strain Guidance	3		
1.3.13 Strain Metric	3		
1.3.14 Strain-Rate	3		
1.3.15 Strain Gage	3		
1.3.16 Strain Gage Element	4		
1.4 Revision Level Changes	4		
2 APPLICABLE DOCUMENTS	4		
2.1 IPC (Normative)	4		
2.2 ASTM (Informative)	4		
2.3 Other Publications (Informative)	4		
3 GENERAL REQUIREMENTS/GUIDELINES	4		
3.1 Boards	6	Figure 1-1 Examples of Solder Joint Damage (top: pad cratering, bottom left: bulk solder joint failure, bottom right: solder interfacial fracture)	2
3.2 Components and Devices	8	Figure 1-2 Area Array Component	3
3.2.1 Area Array Components	8	Figure 1-3 Diagonal strain metric is the maximum of ϵ_2 or ϵ_4 , whichever strain is greater along these two directions, relative to the component.	3
3.2.2 Non-Area Array Components	8	Figure 3-1 Example Board Assembly Process Steps for Strain Measurement	5
3.3 Strain Gage	9	Figure 3-2 Example System Assembly Process Steps for Strain Measurement	5
3.3.1 Strain Gage Placement of Area Array Components	10	Figure 3-3 PCA with SMT Components Only (After SMT Reflow)	6
3.3.2 Strain Gage Placement for Non-Area Array Components	12	Figure 3-4 PCA with Both SMT and Through-Hole Components (After Wave Solder)	7
3.4 Gage Attachment	12	Figure 3-5 ICT Fixture Strain Gage Test Setup	7
3.5 Lead Wires	13	Figure 3-6 Stacked Rosette Strain Gage	9
3.6 Measurement Equipment	14	Figure 3-7 Strain Gage Dimensions (Inches)	9
3.7 Measurement Calibration	14	Figure 3-8 Recommended Gage Placement for BGA Components	10
3.8 Manual Simulation	14	Figure 3-9 Interference Due to BGA Pushdown Block	11
3.9 Strain Metric	15	Figure 3-10 Interference Due to ICT Probe	11
		Figure 3-11 Centroid of Gage Placement Above Corner Land Pad	12
		Figure 3-12 Component Removal to Facilitate Gage Placement	12
		Figure 3-13 Uni-Axial Strain Gage Placement for MLCC packages (within 1.0 mm of solder fillets)	12
		Figure 3-14 Lead Wire Routing Example	13
		Figure 3-15 Example Gage Correlation Tool	14
		Figure 4-1 Time History of the Strain Limit Criteria	15

Figures

Figure A-1	Illustration of Support “skate” when a UUT’s Support is Overloaded with Upward Pressure, Causing it to Collide with a Component.	18
Figure A-2	Illustration of UUT Support Areas and Keep-out Areas around a BGA component	19
Figure A-3	Illustration of Component to Support Clearance and Proper Support Alignment	20

Tables

Table 4-1	Example Strain Report for a Strain Gaged Component that went through Various Handling and Assembly Processes	17
-----------	--	----

Printed Circuit Assembly Strain Gage Test Guideline

1 SCOPE

This document is meant to be used as a methodology for strain gage placement and subsequent testing of Printed Circuit Assemblies (PCAs) using strain gages. The method describes specific guidelines for strain gage testing of PCAs during the printed board manufacturing process, including assembly, test, system integration, and other types of operations that may induce board flexure.

The suggested procedure enables printed board assemblers to conduct strain gage testing independently, and provides a quantitative method for measuring board flexure, and assessing risk levels.

The topics covered include:

- Test setup and equipment requirements
- Strain measurement
- Report format

This document assumes the methodology is being used to test a surface mount device such as Ball Grid Array (BGA), Small Outline Package (SOP), Chip Scale (Size) Package (CSP), and area-array surface mount (SMT) connectors/sockets. In certain cases, the described test approach may be used for non-area-array discrete SMT devices such as capacitors or resistors.

1.1 Purpose Strain gage testing allows objective analysis of the strain and strain rate levels to which a surface mount component may be subjected during PCA assembly, test, and operation.

Characterization of worst-case PCA strain is critical due to the susceptibility of component interconnects to strain-induced failures. Excessive strain can result in various failure modes for different solder alloys, package types, surface finishes, or laminate materials. Such failures include solder ball cracking, trace damage, laminate related adhesive failure (pad lifting) or cohesive failure (pad cratering) and package substrate cracking (see Figure 1-1).

1.2 Background Board flexure control using strain gage measurement has proven beneficial to the electronics industry, and continues to gain acceptance as a method to identify and improve manufacturing operations that can pose a high risk for interconnect damage. However, with the rapid transition to lead-free assembly technology, increased interconnect densities, and new laminate materials, the potential for flexure-induced damage has increased. Many board assemblers are now required to operate under strain levels specified by their customers or component suppliers.

As strain measurement technology has matured, different methodologies have developed. Variations in strain gage methodology inhibit reliable data collection and prevent data comparison across the industry. This document provides a standardized set of guidelines to address variations in gage mounting, gage placement, experiment design, data acquisition system variables, and strain metrics.

PCA strain measurement includes application of strain gages to the printed board near specified components, followed by subjecting the instrumented board to various test, assembly, and handling operations. Steps which exceed strain limits are deemed excessive and are identified so that corrective actions can be made. Strain limits may come from the customer, component supplier or internal best known practices. Examples of strain measurement criteria are shown in the www.ipc.org/IPC-WP-011 white paper.

By identifying areas sensitive to manufacturing variation, strain gage testing provides insight into the effects of a production ramp. Strain gage measurements become the baseline for future process improvement activities, and quantify the effectiveness of adjustments. Manufacturing steps that are typically characterized are listed below:

1. SMT assembly process:

- Printed board depopulation processes
- All manual handling processes
- All rework and retouch processes
- Connector installation
- Component installation